





Preparation

The battery pack


1 Charge the battery pack until the CHARGE lamp lights off. For customers in the U.S.A. and Canada



For customers in countries/regions other than the U.S.A. and Canada




2 Insert the battery pack into the camera.



Firmly insert the battery pack all the way while pressing the lock lever with the tip of the battery.

The lens

1 Remove the body cap on the camera and packaging lid on the rear of the



- Do not touch inside parts.
- If dust enters the camera, it may appear on the photo image. Do not leave the camera and lens without the caps. When you change the lens, do it quickly in a location free from
- 2 Mount the lens by aligning the index marks as illustrated.




- Turn the lens until it clicks.
- Remove the lens cap during shooting.

The memory card



2 Insert a memory card and select the type of the memory card you want to use using the memory card switch. Face side (SD memory card)




Terminal part

- When inserting a memory card, turn the camera off.
- For available memory cards, refer to the Instruction Manual.

Date/time setup

1 Turn the camera on.



2 Set up the date/time.







Look into the viewfinder.

Set the mode dial to AUTO.

Shooting

 Adjust the diopter-adjustment dial if the focus of the viewfinder is not achieved.




Hold the grip of the camera.


Support the lens from

3 Press the shutter button halfway down to focus.

- Pressing the shutter button halfway down and holding it activates the autofocus
- 4 Press the shutter button fully down to shoot.







To fully enjoy the features of your single lens reflex camera, consult the "Instruction Manual."

